

	SaarFloor DIAMANT	SaarFloor NOPPE	SaarFloor BERNSTEIN
<b>Supplier</b>			
<b>ARDEX GmbH</b>	AF 2224 AF 140	AF 2224 AF 140	AF 2510
<b>Bostik GmbH</b>	Bostik's Best Bull Force	Bostik's Best Bull Force	Nibofloor PU 16 Bostik's Best*
<b>MAPEI GmbH</b>	Ultrabond Eco V4 SP	Ultrabond Eco V4 SP Ultrabond Eco S1000 1K	Ultrabond Eco S1000 1K Adesilex G19
<b>PCI Augsburg GmbH</b>	GKL 354	2K-PU GKL-354* GKL 356*	2K-PU GKL 354* GKL 356*
	K 150 K 188 E	K 150 K 188 E	R 710 K 150*
<b>Sika Deutschland GmbH</b>	Emiclassic	Schönox PU 900 Emiclassic*	Schönox PU 900 Emiclassic*
<b>Uzin Utz AG</b>	KE 66 KE 2000S	KE 66 KE 2000S	KE 430 KE 66*
<b>Wakol GmbH</b>	D 3318 PU 270*	PU 270 D 3318*	PU 270 D 3318*

\* please consult the adhesive manufacturer

All the adhesives that we recommend must be used in accordance with the respective manufacturer's specifications.

Any adhesives that are not listed in this recommended list have not been tested. They have not been tested for compatibility with our products.