

Heterogeneous, woven vinyl floor covering

**POLYFLOR
WOVON**
Supplier **Wet and adhesive bed adhesives**
ARDEX GmbH AF 155
Bostik GmbH Bostik's Best
G.A. Kiesel GmbH Okatmos star 100
PCI Augsburg GmbH Thomsit K 188 E
Thomsit K 190 F
PCI UKL 302
Uzin Utz AG KE 2000 S
Thermosetting resin adhesives
G.A. Kiesel GmbH Okamul PU
MAPEI GmbH G19
PCI Augsburg GmbH Thomsit R 710
Thomsit P 625
Uzin Utz AG KR 430

The specified adhesives require a uniformly absorbent substrate.

The floor must be carefully rolled or rubbed on after insertion.

All adhesives recommended by us must be processed according to the manufacturer's instructions.

Only these adhesives are suitable for use and application.

Any adhesives that are not listed in this recommended list have not been tested. They have not been tested for compatibility with our products.

Note:

A thermosetting resin adhesive must be used when installing floor coverings in conservatories or rooms with large banks of windows with a high level of solar radiation.